



NOTE: If you're building your tunnel, Fix BBB32 to hoop **before** sheeting the tunnel.

If retro fitting, it's advisable to fit the BBB32 near the bottom of the hoop and slide it up over the hotspot tape

Remember to apply hotspot tape to the outside edge of the BBB32 clamp

TOP TIP: Use a piece of timber (not included) to stabilise the leg and to stop it sinking.

PLEASE NOTE: MAXIMUM THICKNESS OF TIMBER IS 45MM, TIMBER IS **NOT** SUPPLIED

SECTION 2.7 - STAGING SUPPORT INSTALLATION

SECTION 2.7.1 - INSTALLATION